




Countertop Oven Cooking Tips

Tip #1: How To Use Tin Foil

Tin Foil can be used to wrap foods on the cooking rack.




Tip #2: How NOT To Use Tin Foil

But, Tin Foil should NOT be used on the drip tray, near the heating elements, or near the interior walls or door of the oven.



Tip #3: USE Oven Safe Cookware

Only oven-safe cookware should be used in your Oster® Countertop Oven. This is because oven-safe cookware is specifically made to withstand the high temperatures of an oven,



Tip #4: Cookware-Precaution

It is not advised to cook or re-heat foods in:

- coffee cups
- dinnerware plates or bowls
- or plastic storage containers



Tip #5: Proper Cleaniing

To clean, wipe with a damp cloth using ONLY mild, soapy water. DO NOT immerse in water or use chemical oven cleaners, abrasive cleaners, or scrubbing brushes which can damage the oven's coating.

