




Quick Start Reference Guide*

Oster Pro™ 500 Blender Model BLSTTA

***WARNING:** This Quick Start Guide is not intended to be a substitute for the Owner's Manual, and you should read and understand the warnings and instructions in the Owner's Manual before using this appliance.

Parts & Accessories



(Blender Jar and Blender Base may appear different from shown.)

IMPORTANT: Your Oster® Blender has been shipped with the components shown above. Check everything carefully before use. If any part is missing or has been damaged in shipping do not use the product and contact Customer Service at 1-888-233-3214.

STOP


Please do not return product to the place of purchase!

Call 1-888-233-3214 or visit www.osterblending.com

Step 1


Assemble Blender

Clean your Blender Base by using a damp, soft sponge with mild detergent. All parts except for the Blender Base are dishwasher-safe. Parts can also be washed in warm, soapy water. Rinse well and dry.




A) Turn Blender Jar upside down and place sealing ring over bottom opening of Blender Jar.

Carefully place Blade System into the Blender Jar.




B) Screw Threaded Bottom Cap onto the bottom of the Blender Jar and tighten securely.



C) Place assembled Blender Jar on top of Blender Base.

Be sure to line up tabs on Blender Jar with the tabs on the Blender Base.



D) Make sure Blender Jar is fully seated in position. You are now ready to blend!

Step 2

Add Ingredients/Secure Blender Lid



- A) Add ingredients to the blender jar.
- B) Place Blender Lid with Filler Cap on Blender Jar, and ensure lid is tightly sealed.
- C) Plug the power cord into a 120 Volt AC electrical outlet.

NOTE: For best results always add liquids first when blending, unless a recipe says otherwise.

Step 3

Begin Blending

Using Pre-Programmed Settings

- A) Press the On/Off button and press the desired Pre-Programmed Settings button: - "Frozen Drink/Smoothies" or "Food Chop/Salsa"
- B) To change your selection, press "STOP" followed by another Pre-Programmed or Manual Setting button.
- C) Once the program is finished the cycle automatically stops. Press the "STOP" button to cancel the program at any time. The blinking blue light indicates that the blender is ready.
- D) Press the On/Off button to turn the blender off.

Using Manual Settings

- A) Press the On/Off button and press the desired Manual Setting: High/Medium/Low
- B) Press "STOP" to cancel the operation at any time.
- C) Press the On/Off button to turn the blender off.

Pulse Settings

Use the Pulse button for chopping. Press and hold the desired Pulse (Low or High) button down for desired length of time. Release button and allow blade to stop. Repeat cycle as needed.

Blending Tips

- Put liquids in the Blender Jar first, unless a recipe says otherwise.
- Crushing ice: Crush 6 ice cubes or approximately 2 cups of ice at a time. Cover ice with about 1 cup (0.236 liter) of water for best results.
- Do not remove the Blender Lid while in use. Remove Filler Cap to add smaller ingredients.
- Cut all firm fruits and vegetables, cooked meats, fish and seafood into pieces no larger than ¾ inch (1.9 cm) to 1 inch (2.5 cm). Cut all kinds of cheeses into pieces no larger than ¾ inch (1.9 cm).

Recipes

For fun and creative recipes for your new Oster® Blender please check the Blender instruction booklet or visit www.osterblending.com.

For the perfect recipe for any occasion – turn on your creativity with an Oster® Blender!